

FENDER "BASS-MAN" LAYOUT

MODEL 5E6-A

A-EE

NOTICE

VOLTAGES READ TO GROUND
WITH ELECTRONIC VOLTMEETER.
VALUES SHOWN + OR - 20 %



