



T1	Power Transformer	TF-7795	R76	Control - 250K, A (Depth)	GBA-811-3701
T2	Output Transformer	TF-501-0	R6, R9, R10, R14, R16	Controls - 1 meg, A (Bass, Treble, Loudness, Reverb)	GBA-811-1709
T3	Reverb Transformer	TF-8440	R7, R8	Control - 1.1 meg, B (From)	GB-811-1711
	Filter Choke	TF-3721H	R50	Control - 500 ohm, W (no stop)	DB-21391
S5A, B, C, D	Switch - polarity	SM-78A	R75	Light Dependent Resistor	L28-500
S1A, B, S2A, B	Switches - OFF/Slide	SM-129	Z1	10", 8 ohm Speakers	S-20005
S3, S4	Switches - SPST	SM-8260	O1, O2		
I1	Pilot Light (Amber) Neon	PL-12A			
I2	Pilot Light (Red) Neon	PL-12R			
D1A, B	Diode - 1200 PIV, 750 MA	DE-57			
D2	Diode - 200 PIV, 1 A D	DI-405			

