

GA-75

CHANNEL I

CHANNEL II

V1B 223V

V1A 223V

V2A 228V

V2B 228V

V3 234V

V4A 224V

V4B 224V

V5 468V

V6 468V

GA-75-L

SP1 16Ω

MONITOR JACK

NE1

NE2

SW1C

SW1B

SW1A

2 AMP S.B.

GROUND CLIP

110-125V AC 50-60~

GA-75

SP2 8Ω

SP3 8Ω

SW-1A, 1B, 1C, 1D

DI-1, DI-2

D3

R6, R37

R7, R11

R38, R42

Control - 500K, C2 Audio Taper (Loudness)

(Treble and Bass)

Controls - 1 meg, C2 Linear Taper Bass

SW-78

DI-57

DI-69A

CBA-811-3707

CBA-811-3709

TP-77PS

TP-300-01

TP-3021H

D-130 S-20005

SP-1 15", 16 ohm Speaker

SP-2 & 3 10", 8 ohm Speakers

T1 Power Transformer

T2 Output Transformer

L1 Filter Choke

SW-1A, 1B, 1C, 1D AC Power Switch, off, standby, on-on

DI-1, DI-2 Diode - 1200 PIV, 250 MA

D3 Diode - 200 PIV, 250 MA

R6, R37 Control - 500K, C2 Audio Taper (Loudness)

R7, R11 (Treble and Bass)

R38, R42 Controls - 1 meg, C2 Linear Taper Bass

SW-78

DI-57

DI-69A

CBA-811-3707

CBA-811-3709

TP-77PS

TP-300-01

TP-3021H

D-130 S-20005

SP-1 15", 16 ohm Speaker

SP-2 & 3 10", 8 ohm Speakers

T1 Power Transformer

T2 Output Transformer

L1 Filter Choke

SW-1A, 1B, 1C, 1D AC Power Switch, off, standby, on-on

DI-1, DI-2 Diode - 1200 PIV, 250 MA

D3 Diode - 200 PIV, 250 MA

R6, R37 Control - 500K, C2 Audio Taper (Loudness)

R7, R11 (Treble and Bass)

R38, R42 Controls - 1 meg, C2 Linear Taper Bass

