

HOW TO ORDER PARTS FOR YOUR GUIDE

These authorized replacement parts may be ordered through the dealer from whom the amplifier was purchased.

1. The PART NUMBER (number printed on part, if different from that shown in this list) and the DESCRIPTION AND RATING. When no number is assigned, order by DESCRIPTION AND RATING.
2. The MODEL number will be found on the sticker on the inside of your amplifier cabinet.

PARTS LIST

<u>SCHEMATIC LOCATION</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>SCHEMATIC LOCATION</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
	2407	Cabinet	C1	205	40-40-40-150-Cord
	400	Speaker		I105	Socket - 7 Pin
	400-T	Output Trans.		I104	Socket - 8 Pin
	301	Handle	C2	206	.005-MFD-1000V
R1	1600	1/2 Meg. Control	C3	204	.05-MFD-400V
R2	1601	1 Meg " W/S	R3	127	150-OHM-5 Watt Res.
	1500	Knob	R4	112	3300-OHM-1/2 " "
	900	Jack	R6	102	22,000 " " "
	2000	10 ft. Cord	R7	117	3.9 meg " " "
	807	Tube 35Z5	R9	126	2.2 Meg " " "
	808	Tube 50L6	R10	128	680,000 " " "
	809	Tube 12AU6			
T1	1705	Isol. Transformer			

